## EZ CANBUS CHARGING REQUEST



Pinkwire to switched 12 voltsBlackwire to GroundBrownwire to GM CAN+Tanwire to GM CAN -

When wired properly this unit will send the GM alternator charging rate signal so you can run the stock GM alternator without it being in fail safe mode. you should see around 13.8 - 14.4 volts depending on the load.



